



**HAND BLENDER
SINGLE**

HBL800-WH

INSTRUCTIONS MANUAL


THANK YOU FOR CHOOSING IDO PRODUCTS

ENGLISH

COMPONENTS

HAND BLENDER

1. Speed "1" button
2. Speed "2" button
3. Motor unit
4. Blade lock / release button
5. Immersion Rod
6. Measuring Beaker



SAFETY INSTRUCTIONS

PLEASE CAREFULLY READ THE INSTRUCTIONS BEFORE USING YOUR APPLIANCE

1. Please keep your instructions manual, the warranty certificate and purchase voucher.
2. Check that electrical installation is in conformity with currently Applicable Standards, compatible with the power and the voltage indicated underneath your appliance. If this is not the case, don't use the appliance.
3. The appliance is made for household use only.
4. If there are any defects in the appliance or its cord cease its use immediately and contact the nearest service centers of **Anasia**.
5. Any intervention other than cleaning, such as normal maintenance must be carried out by an approved **Anasia** service center.
6. Don't put the appliance or its cord or the plug into water or any other liquid.
7. Unplug the appliance as soon as you stop using it, before assembly, disassembly and during the cleaning process.
8. For your own safety, only use original parts and accessories designed for your appliance.
9. Don't touch any rotating or moving parts while still in motion; always wait for them to stop.
10. Keep the appliance and its cord out of reach of children.
11. The blades are very sharp, take care while handling them, while emptying the bowl or during the cleaning.

BEFORE FIRST USE

- Remove all packaging material before using your appliance for the first time and read the operation instructions.
- Wipe the body with a damp cloth and dry it well.
- The hand blender can be washed with warm soapy water, rinse after cleaning and dry thoroughly with a soft dry cloth.

USING YOUR APPLIANCE

- Prepare the ingredients to be whisked in a suitable container or in a beaker (6) .
- Install the immersion rod (5) on the motor unit (3) until it clicks into place.
- Put the hand blender in the container or in a beaker.
- Connect the appliance to a suitable electrical source.
- Set the desired speed from (1:2).
- After you finish mixing, disconnect the appliance from the main outlet.
- Then click on the release button (5).

CLEANING AND MAINTENANCE

- Remove the plug from the wall socket.
- Clean the motor unit (3) with a damp cloth after use.
- Wash the attachments with water and washing liquid.

TECHNICAL SPECIFICATION

POWER	VOLT	FREQUENCY
800 W	220-240 V	50-60 HZ

TROUBLE SHOOTING

What to do if your appliance doesn't work?
Check:

- It is correctly plugged in the wall socket.
- The blade is inserted correctly.

If your appliance is still not working, contact **Anasia** customer service.

**MANUFACTURED ACCORDING TO THE
EGYPTIAN STANDARD NO. 1590/2010**

**MADE IN EGYPT FOR ANASIA EGYPT
FOR TRADE**

الخصائص الفنية

استخدام الجهاز

القدرة	فولت	تردد
٨٠٠ واط	٢٢٠-٢٤٠ فولت	٥٠-٦٠ هرتز

استكشاف الاخطاء واصلاحها

- إذا كان جهازك لا يعمل، تأكد من أن
- تم توصيل الجهاز بالتيار الكهربائي.
- تم تركيب السلاح بشكل صحيح.
- إذا استمر جهازك لا يعمل ، يرجى الاتصال بخدمة عملاء أنسيا.

**صنع طبقاً للمواصفات القياسية المصرية
رقم 2010/1590**

صنع في مصر لصالح شركة أنسيا مصر للتجارة.

- قم بتجهيز المكونات المراد خفقتها في وعاء مناسب او في كوب المعايير (٦).
- ركب سلاح الخلط (0) على وحدة الموتور (٣) حتى تستقر في مكانها.
- ضع الخلط اليدوي في الوعاء.
- صل الجهاز بمصدر كهربائي مناسب.
- قم بالضغط على السرعة المطلوبة من ٢:١.
- بعد الانتهاء من الخفق افصل الجهاز عن التيار الكهربائي.
- ثم قم بالضغط على زر إزالة السلاح (٤).

التنظيف والصيانة


- افصل الجهاز عن الكهرباء.
- نظف وحدة الموتور (٣) بقطعة قماش رطبة بعد كل استخدام.
- اغسل الملحقات بالماء الدافئ وقليل من سائل التنظيف.

كتيب التعليمات

نشركم لاختيار منتجات أي دو

اجزاء الجهاز

الخلط اليدوي



١. زر السرعة الاولى
٢. زر السرعة الثانية
٣. وحدة الموتور
٤. زرار تركيب/ازالة السلاح
٥. سلاح الخلط
٦. دورق الخفق

تعليمات السلامة

برجاء قراءة التعليمات بعناية قبل الاستخدام لأول مرة

١٠. يجب ابقاء الجهاز وكابل الطاقة بعيدا عن متناول الأطفال.
١١. لا تضع أجزاء معدنية أو صلبة داخل الجهاز أثناء التشغيل.

قبل الإستخدام لأول مرة

- قبل استخدام الجهاز لأول مرة ينبغي التأكد من إزالة كافة مواد التغليف وقراءة تعليمات التشغيل.
- امسح جسم الموتور بقطعة قماش مبللة وجففها جيدا.
- يمكن غسل الهاندبلندر بالماء الدافئ وسائل تنظيف قم بالشطف بعد التنظيف وقم بالتجفيف جيدا باستخدام قطعة قماش ناعمة جافة.

١. برجاء الاحتفاظ بكتيب التعليمات و شهادة الضمان و قسيمة الشراء.
٢. تأكد أن قوة التيار الكهربائي الخاص بالجهاز متطابقة مع قوة التيار الكهربائي للمنزل.
٣. صمم هذا الجهاز للاستخدام المنزلي فقط.
٤. لا تستخدم الجهاز إذا كان به تلف أو لا يعمل بشكل صحيح في مثل هذه الحالة اتصل بمركز خدمة معتمد من قبل أنسيا.
٥. أي تدخل في الجهاز غير التنظيف يجب أن يتم من خلال مركز خدمة معتمد من أنسيا.
٦. لا تغمر الجهاز أو الوصلة الكهربائية في الماء أو أي سوائل أخرى ولا تستخدم الجهاز بأيدي مبللة.
٧. افصل الجهاز دائما عن التيار بعد الانتهاء من استعماله و قبل الفك والتركيب أو قبل تنظيفه.
٨. لسلامتك الشخصية استخدم فقط قطع الغيار والملحقات الأصلية المناسبة لجهازك.
٩. يجب عدم لمس الشفرات الحادة أثناء التشغيل كما يجب الانتظار حتى يتوقف الجهاز تماما.

WAYS TO ACTIVATE YOUR WARRANTY (2 YEARS WARRANTY)

1. Scan the QR code at the bottom on the page.
OR
2. Visit our website www.anasiashop.com
OR
3. Through our mobile application.

MAINTENANCE & CUSTOMER SERVICES

ANASIA, CAIRO

9, Mostafa Refaat St. Sheraton
Heliopolis, Cairo

ANASIA, ALEX

23, Essam Helmy El-Masry St. off Admon
Fremont St. Semouha, Alexandria

ANASIA, MANSOURA, DELTA

2, Ibrahim Shalaby St. off Samia El-Gamal
St. Mansoura

CUSTOMER SERVICE

(02) 22684159

طرق تفعيل الضمان (سنتين ضمان)

١. امسح رمز QR كود في اسفل الصفحة.
أو
٢. قم بزيارة موقعنا الإلكتروني www.anasiashop.com
أو
٣. من خلال تطبيق الموبيل.

مركز الصيانة وخدمة العملاء

شركة أنسيا فرع القاهرة

٩ شارع مصطفى رفعت
مساكن شيراتون، القاهرة

شركة أنسيا فرع الإسكندرية

٢٣ شارع عصام حلمي المصري
متفرع من آدمون فريمون سموحة، الإسكندرية

شركة أنسيا فرع المنصورة، الدلتا


٢ شارع إبراهيم شلبي
متفرع من سامية الجمل، المنصورة

خدمة العملاء

٢٢٦٨٤١٥٩ (٠٢)



HOTLINE
الخط الساخن



DOWNLOAD ANASIA SHOP APP

